



QUICK TIPS

CONTRACTOR TIP

by Corey Zussman, QAQC Vice President, AECOM Hunt

air barrier

abaa
association of
america

Precision Points: Scupper Detailing

It's easy to forget the air barrier transition into a scupper with the roofing membrane if the drawings are not clear or do not provide adequate detailing.

When a scupper is to be installed, provide a transition membrane and make sure that all materials are compatible in the direction of the installation.

It is recommended to install the transition membrane (light blue) first, with the roofing and air barrier installed over the compatible transition membrane to ensure the best installation and easiest material compatibility.

